

### PRELIMINARY COCKPIT PREP (SILENT)

ENG MODE SEL. .... NORM  
\* WEATHER RADAR. .... OFF  
L/G lever ..... DOWN  
Both WIPER selectors ..... OFF  
BAT ..... CHECK/AUTO  
EXT POWER ..... ON  
APU FIRE ..... CHECK/TEST  
APU. .... AS RQRD  
When APU AVAIL:  
AIR COND panel ..... SET  
EXT POWER ..... AS RQRD  
\* COCKPIT LIGHTS ..... AS RQRD  
\* ECAM RCL pb ..... PRESS  
\* ECAM OXY PRES/HYO QTY/ENG  
\* OIL QTY ..... CHECK  
FLAPS. .... CHECK POSITION  
\* SPD BRK LEVER CHECK RET AND DISARMED  
\* PARKING BRAKE. .... ON  
\* ACCU/BRAKES PRESS. .... CHECK  
\* OEB IN QRH. .... CHECK  
EMER EQPT. .... CHECK  
RAIN REPELLENT ..... CHECK  
C/B panels ..... CHECK  
\* GEAR PINS/FAN COWL FLAGS ..... CHECK  
AIRCRAFT LIBRARY ..... CHECK  
Only asterisks (\*) items required on transit stop.

### BEFORE START

COCKPIT PREP ..... COMPLETED (BOTH)  
SIGNS ..... ON/AUTO  
ADIRS ..... NAV  
FUEL QUANTITY ..... KG./BALANCED  
FMGS ..... SET  
ALTIMETERS ..... SET/xxxFT(BOTH)

WINDOWS/DOORS ..... CLOSED/ARMED (BOTH)  
BEACON ..... ON  
MOBILE PHONE. .... OFF (BOTH)  
PARKING BRAKE ..... ON

### AFTER START

ANTI ICE ..... AS RQRD  
ECAM STATUS ..... CHECKED  
PITCH TRIM ..... % SET  
RUDDER TRIM ..... ZERO

### BEFORE TAKEOFF

FLT CTL. .... CHECKED (BOTH)  
BRIEFING ..... CONFIRMED  
FLAP SETTING. .... CONF (BOTH)  
FMA & TAKEOFF DATA ..... READ (PF)  
..... CHECKED (PM)  
TRANSPONDER. .... SET  
ECAM MEMO ..... TAKEOFF NO BLUE  
EFB ..... AS RQRD (BOTH)

CABIN ..... SECURED FOR TAKEOFF  
ENG MODE SEL. .... AS RQRD  
TCAS. .... TA/RA  
PACKS. .... AS RQRD  
ANTI ICE ..... AS RQRD

### APPROACH

MINIMUM ..... SET (BOTH)  
ENG MODE SEL. .... AS RQRD  
EFB ..... AS RQRD (BOTH)

### LANDING

CABIN ..... SECURED FOR LANDING  
AUTOTHRUST ..... SPEED/OFF  
GO-AROUND ALT ..... FT SET  
ECAM MEMO ..... LANDING NO BLUE  
LDG DOWN  
SIGNS ON  
SPLRS ARM  
FLAPS SET

### PARKING (SILENT)

APU BLEED ..... AS RQRD  
Y ELEC PUMP ..... OFF  
ENGINES ..... OFF  
SEAT BELTS. .... OFF  
EXT LT ..... AS RQRD  
PARK BRK and CHOCKS. .... AS RQRD  
MOBILE PHONE. .... ON  
TRANSPONDER. .... STANDBY 2000  
RADAR/PWS ..... OFF  
Consider HEAVY RAIN  
EXTRACT ..... OVRD

### SECURING THE AIRCRAFT (SILENT)

EFB ..... BOTH OFF  
FUEL PUMPS ..... OFF  
ADIRS ..... OFF  
OXYGEN. .... OFF  
APU BLEED ..... OFF  
EMER EXIT LT ..... OFF  
PARKING BRAKE. .... ON  
NO SMOKING. .... OFF  
APU AND BAT ..... OFF  
Consider COLD WEATHER

### RUNWAY CHANGE/TAKEOFF DATA AIDE MEMOIRE

F-PLN (Runway & SID). .... REVISE AS RQRD  
EOSID. .... REVIEW  
FCU ALTITUDE. .... REVISE AS RQRD  
With Aircraft Stationary:  
TAKEOFF PERF. .... REVISE AS RQRD  
BEFORE TAKEOFF CHECKLIST. .... COMPLETE

## [QRH] EMER EVAC

AIRCRAFT/PARKING BRK .....STOP/ON  
 ATC (VHF1) ..... NOTIFY  
 CABIN CREW (NOTIFY) ..... ALERT  
 ΔP (only if MAN CAB PR has been used) ..... CHECK ZERO

If ΔP not at zero:

CAB PR MODE SEL ..... MAN  
 VS/CTL..... FULL UP  
 ALL ENG MASTERS ..... OFF  
 ALL FIRE pb (ENGs & APU) ..... PUSH  
 ALL AGENTS (ENGs & APU) ..... AS RQRD

If evacuation required:

EVACUATION ..... INITIATE

If evacuation is not required:

CABIN CREW AND PASSENGERS (PA) ..... NOTIFY